


PORTABLE COUNTER LARGE RECTANGLE

HARDWARE & INSTALLATION INSTRUCTIONS



WHAT'S INCLUDED:

- (1) 15.5" WIDE BLACK LAMINATED COUNTERTOP (TOP SURFACE)
- (1) 15.5" WIDE SILVER BASE PANEL WITH TWO CUT-OUT HANDLES (BOTTOM SHELF / FLOOR BASE)
- (8) LEG PIECES – TOP & BOTTOM SECTIONS
 - (4) BOTTOM POLE PIECES
 - (4) TOP POLE PIECES
- ALL POLES ARE TELESCOPING AND PRESS-FIT — NO TOOLS REQUIRED
- NYLON CARRYING CASE



PORTABLE COUNTER LARGE RECTANGLE

HARDWARE & INSTALLATION INSTRUCTIONS CONTINUED



STEP 1

Turn the 15.5" wide black laminated countertop upside down on a flat surface.
Locate cylinder Leg piece with screw and align one top pole piece with a corner hole.



STEP 2

- Twist the pole clockwise to screw it securely into the corner insert.
- Repeat for all four corners.



STEP 3

- Twist the pole clockwise to screw it securely into the corner insert.
- Repeat for all four corners.
- Connect all top cylinder leg pieces



STEP 4

- Place the 15.5" wide silver base panel on the floor with the cut-out handles facing up.
- Repeat the same process as Step 2.



STEP 5


- Lower the countertop with attached legs onto the base, guiding each leg into the four corner holes.
- Press down until all legs are seated securely in the base.

STEP 6

- Lift the counter carefully and turn it upright.
- Your Large Rectangle Portable Counter is now fully assembled and ready to use.

PORTABLE COUNTER LARGE RECTANGLE

HARDWARE & INSTALLATION INSTRUCTIONS CONTINUED



STEP 1

- Hold the sleeve with the graphic facing outward.
- Slide it down over the top of the frame.

STEP 2

- Press the stitched seam of the fabric firmly into the channel around the base panel.



STEP 3

- Work around the entire base, pushing the silicone beading fully into the edge groove.
- Smooth the fabric tight as you go to remove wrinkles.

STEP 4

- Pull the remaining fabric evenly around all four sides.
- Make sure the graphic is centered and straight.



STEP 5

- Finish seating the beading at the corners of the base panel.
- Double-check that all edges are fully pressed into the channel.

STEP 6

- Carefully flip the counter upright.
- Make final graphic alignment adjustments.