

SILICONE EDGE GRAPHIC (SEG) STRETCH FABRIC STAND (BACKLIT)

HARDWARE & INSTALLATION INSTRUCTIONS



SEG STANDS INCLUDE:

- (2) 6'X7' FRAME WITH LED LIGHT PIECES
- (2) 39 ³/₈ WIDE TOP & BOTTOM PIECES
- (1) 4' CENTER CYLINDER BAR PIECE
- (1) 70" POWER CORD



SEG STRETCH FABRIC STAND (BACKLIT)

HARDWARE & INSTALLATION INSTRUCTIONS CONTINUED



STEP 1

Find the base piece with the rotating feet. Rotate the feet outward until they are in the standing position. Then, connect the white wall plug cord to the built-in adapter, matching the arrows for correct alignment.



STEP 2

Connect the side frame pieces by matching the numbers on each part. (For example, piece 1 attaches to 1, piece 2 to 2, & so on.)



STEP 3

Slide the cylinder rod into the horseshoe-shaped notch on Side Piece 2 & Side Piece 5, ensuring it rests securely in both notches.



STEP 4

Connect the two power supply cords to the power supply ports located on Side Piece 5 & Side Piece 2



STEP 5 & 6

Plug the attached white cord into Side Piece 1 and Side Piece 6, ensuring both connections are secure.

Plug in the main power cord to test that the lights on the stand are working before installing the SEG banner. ⚠ **Warning:** Lights become extremely bright if turned on without the SEG banner attached. You may want to attach a banner before testing the lights to avoid excessive brightness & to protect your eyes.